


CAMcourse replacement of camera:

- Locate junctionbox “monitor”, and open it.
- Completely switch of the CAMcourse system by removing the two power plugs within the junctionbox “monitor”.



unplug

- Release monitor by pressing the two buttons on each side of mounting frame.



- Pull out monitor cable cautious until you reach connector.
- Unplug connector and replace monitor.



- Reassemble in reverse order!